

**STUD**  
CENTERLINE

**STUD**  
CENTERLINE

**Cut drywall on  
this solid line**

**14.5 inches wide**

**Velodyne**<sup>®</sup>

SC-600IW Installation Template

[www.velodyne.com](http://www.velodyne.com)

345 Digital Drive  
Morgan Hill, CA 95037  
408.465.2800

88-SC600IWCU Rev E3

### Quick Install Guide

*For more details see Instruction Manual*

- 1) Select Location for In-Wall installation
- 2) Unpack both cartons
- 3) Locate edge of 2"x4" studs  
(Note: Designed for 16" center spacing)
- 4) Attach template to wall
- 5) Cut out drywall per template
- 6) Route wire into opening
- 7) Connect wire
- 8) Install In-Wall assembly into opening
- 9) Install Grille

**16.67 inches tall**

**Cut drywall on  
this solid line**