

Cut drywall on this solid line

Cut drywall on this solid line
16.5 inches wide

Quick Install Guide - Designer Grill

For more details see Installation Manual

- 1) Select location for In-Wall installation
- 2) Unpack both cartons
- 3) Locate edge of 2" x 4" studs
(Note: Designed for 16" on center spacing)
- 4) Attach template to wall
- 5) Cut out drywall per template
- 6) Assemble back box to driver module
- 7) Route wire into opening
- 8) Install In-Wall assembly into opening
- 9) Connect wire
- 10) Install filler plate
- 11) Install additional drywall above filler plate
- 12) Finish wall (tape, mud, texture and paint)
- 13) Remove protective cover on driver
- 14) Install Designer Grill

Velodyne

**SC-IW Installation Template
For Use with Designer Grill**

www.velodyne.com

345 Digital Drive
Morgan Hill, CA 95037
408.465.2800

88-SCIW Rev A

32 inches

STUD

STUD

Negative
(black)
speaker
wire

Positive
(red)
speaker
wire

Edge of stud
(14.5 inch spacing)

Center of stud
(16 inches on center)

Center line

6.375 inches

17.5 inches

Cut drywall on this solid line